

## Installation Instructions:

### Notes:

-Read these instructions all the way through before installation.

-If you do not feel so inclined to install the decals yourself, we recommended having them professionally installed.

-New plastics have a protective residue from the factory that must be removed before installing decals (see step 1).

-Be patient, take your time and plan on spending a few hours installing your new graphics kit.

-After installation avoid gas spillage when refueling as it will seep under the decals and dissolve the adhesive.

**1)** First clean your plastic parts with Methyl Ethyl Ketone to prepare the plastic for adhesion (DO NOT leave M.E.K. soaked rag on plastic for too long, and avoid contact to “hard plastics” such as tail-lights & headlights...it will cause damage). Then clean with soap and water. If there are any deep scratches with burs that extrude from the surface, try shaving them as flush as possible with a razor blade.

**2)** Get out your blow dryer and extension cord...the heat will allow the decal pieces to be more pliable and easier to manipulate.

**3)** Before removing paper from the adhesive side of the decals, hold each piece up to your vehicle to get an idea of how they will line up.

**4)** Spray down area where the first decal piece will be placed, with a spray bottle of soapy water (approximately 6 drops of liquid dish soap in 24 oz. of water). Pick an easy piece to start with...one of the smaller more flat pieces. Gradually apply the graphics piece starting at one end. On larger pieces start from the center and work your way outward. Pay special attention to lining decals up properly to your plastic's shape and to adjacent artwork.

**7)** Use a soft cloth and/or your fingers to massage out kinks and bubbles, take your time!

**5)** On some of the more difficult areas use the hair dryer to help in stretching the vinyl over some of the more contoured areas. The heat will also help to get the vinyl to adhere quicker by drying the moisture from the spray bottle.

**8)** When finished keep checking for kinks and bubbles that may re-appear for the next 15 minutes or so, until adhesive begins to cure. If you can't rub the bubbles out, you can also use a sewing needle to remove them.

Then, **LET IT DRY ON IT'S OWN FOR 48 HOURS!!**

